

USER GUIDE

IMPORTANT!

Congratulations on investing in a Odyssey X STAND 2!


IMPORTANT!

Please read this User Guide

before attempting to assemble and use stand USER GUIDE

Out of Box Inventory List:

- 1 - MAIN X STYLE BASE
- 2 - SPRING LOADED KNOBS
- 2 - TOP TIERS WITH TWO HEIGHT ADJUSTABLE KNOBS 2
- ADJUSTABLE DEPTH SCREW'S WITH EXTENSION BAR



Assembly Steps for the XSTAND2

1. Open your new Odyssey X STAND 2 frame, then adjust desired depth by loosening the adjustable depth screws and sliding the extension bar into place, re-tighten the adjustable depth screws so the unit is secure.
2. Install the two top tiers by placing them one at a time against the main X STAND 2 frame and adjusting to a desired width, safely secure them each with the provided spring loaded knob.
3. Adjust the top tier to desired height by loosening the rear spring loaded knob, adjusting the top tier to position and re-tightening the spring loaded knob. Adjust the Top tier T-bar to a desired degree by also loosening, adjusting the T-bar to position and then re-tighten the spring loaded knob so that it safely secures it to your X STAND 2.
4. DO NOT attempt to mount or hang anything on your stand until your new Odyssey X STAND 2 is securely assembled with all knobs tightened.

www.odysseygear.com

Specifications

- 1 high quality aluminum/steel X style base 1.5" in diameter and is 38.25" tall
- Top tier max height is 19.25"
- Folds up for easy transport
- Total weight: 18 lbs.